

# Lookout Loft 7-Level Cat Tree

## Assembly Instructions

Thank you for your purchase. Follow these step-by-step instructions to properly assemble your Lookout Loft 7-Level Cat Tree.

When assembling your cat tree, assemble vertically as shown on these instructions.

**Max weight limit**  
**40 LB**  
 (18.14 kg)

Be a good pet parent: Read care guides and books, and research quality care for your pet. Contact a pet professional with any additional care questions.


For questions and inquiries, please contact our customer service line at 1-888-824-7257. For online orders, contact us at 1-877-738-6742, or visit us at petco.com.

### ! WARNING

- Read and follow all warnings and instructions in this manual to avoid personal injury, injury to pet, and property damage.
- For pet use only. Not suitable for children.
- To avoid damage, do NOT assemble horizontally on the floor and lift to an upright position. Assemble product vertically as shown in instructions.
- Wall mount is required.
- For additional stability, we recommend placing product against a wall or corner.
- Do not exceed maximum weight limit.
- Inspect product regularly and retighten screws as necessary.
- Always supervise your pet when using this item.
- Inspect product for damage and discard if any part becomes worn, loose, or detached.
- Not recommended for outdoor use.
- Keep all tools and instructions in a safe place for future reference.

### Parts list

Tools needed are included. Check that you have all the parts shown BEFORE assembling your product. If any parts are missing, please contact our customer service line listed at the upper right of this page.




# Lookout Loft 7-Level Cat Tree Assembly Instructions

When assembling your cat tree, place on a flat, stable surface. Assemble vertically, starting at the base.

**CAUTION: FOR PET USE ONLY. NOT SUITABLE FOR CHILDREN.**

Inspect regularly and replace if any part becomes damaged. Do not exceed weight limit. For additional stability, we recommend placing against wall or corner. Not recommended for outdoor use. Do not allow children to climb on or hang from furniture. Check all hardware and connections regularly to tighten as needed.

## COMPLETED CAT TREE




24 L X 33 W X 64 H IN  
(61 L X 84 W X 162.5 H cm)

**Max weight limit 40 LB (18.14 kg)**


Due to ongoing product improvements, product illustration on packaging may not match finished product.

## CARE INSTRUCTIONS

Spot clean only and vacuum when necessary.




**NOTE:** The included wall mount must be installed to help prevent the tree from tipping over and causing injury to people or pets.



Bolt (B) is assembled inside the Upper Condo.

**NOTE:** Loose components will result in damage to the cat tree. Ensure all screws are secure and tighten them again after two days. Check that screws are secure once a month to ensure product's stability.



Attach Angle Brackets (G) to Scratch Ramp (W) using Bolts (D) before attaching Scratch Ramp to underside of Mid Board (U).

Scratch Ramp (W)